Troubleshooting
Cutters get hot when in use

Cutters get hot when in use

↓ YES

Does the drill run at 1,200 to 1,750 rpm? → NO → Change the drill for one that operates at 1,200 to 1,750 rpm

↓ YES

Do the cutters have enough cutter oil? → NO → Apply more oil to the cutters. Do this every 25 tails

↓ YES

Are the tension screws at the right tension? → NO → Adjust tension screws- see the video on MAINTENANCE page

↓ YES

Is there a gap between the cutting faces? → YES → Sharpen the cutters – see video on MAINTENACE page

↓ NO

Is here hair or debris trapped in the cutters? → YES → Disassemble the case and clean the cutters

↓ NO

Try testing again from the start. If the problem persists, contact your local Tailwell distributor